TOMY International, Inc. – Boon Flair & Flair Elite Highchairs

The bolts used to secure the seat to the pedestal base can become loose over time and allow the seat to detach, posing a fall hazard to children.

Flair Elite Highchair		
Model No.	Description	UPC
B751	White / Orange	854622001064
Flair Highchair		
Model No.	Description	UPC
B701	Blue / White	854622001057
B702	White / Orange	854622001422
B703	Pink / White	854622001941
B704	Green / White	813741010920
B706	White / Orange	854622001415
B707	White / Blue	813741011118
B708	Red / White	813741010937
B709	Red / White	813741011590
B716	Green / White	813741011606
B717	White / Orange	813741011453
B718	White / Blue	813741011460
B731	White / Orange	813741011446
B10147	Gray / Green	669028101474
B11068	White / No Pad	669028110681
B11069	Gray / No Pad	669028110698
B11401	White / Gray	669028114016

The following models are affected:



Flair Elite (B751)





Flair Blue / White (B701)

Flair White No Pad (B11068)

Only high chairs with date codes before September 2016 are affected. The model number and manufacturing date code are printed on a label located under the base of the highchair.

If your High Chair is affected, STOP USING IT IMMEDIATELY, and call toll free

1-866-725-4407 between 8:00 a.m. and 4:00 p.m., Central Time, Monday through Friday, email at <u>cs@tomy.com</u>, or online at <u>https://recall.tomy.com</u>, or <u>https://us.tomy.com</u> and click on "Product Recalls" at the top of the page for more information about receiving a free repair kit.